


# 45-05021



# 45-05021

REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	1	41084	Hopper	32	1	43659	Pin, Spring 3/16 x 1
2	1	41316	Hopper Cover	33	1	47209	Gear, Large
3	2	42311	Tube, Hopper Support	34	1	47205	Gear, Small
4	2	28325	Spacer, .31" x .56" x .438"	35	1	26710	Axle
5	1	42004	Tube, Stand	36	1	42304	Plate, Flow
6	2	41924	Tube, T-Handle	37	1	42347	Spring, Torsion
7	2	44482	Grip, Handle	38	2	49449	Plug
8	1	43848	Grip, Control Arm	39	1	44285	Bushing, Hopper Bottom Black
9	2	40880	Wheel	40	1	49898	Clip, Hairpin 5/8
10	2	49870	Bolt, Hex 1/4-20 x 2-1/2	41	1	46855	Pin, Cotter 3/16" x 2"
11	6	1509-69	Bolt, Hex 1/4-20 x 1-3/4	42	1	48934	Hairpin, Agitator
12	2	46699	Bolt, Hex 1/4-20 x 2	43	2	46055	Pin, Spring 1/8 x 1
13	1	43012	Bolt, Hex 1/4-20 x 3/4	44	1	04367	Spreader Impeller
14	15	47189	Nut, Hex 1/4-20 Nylock	45	2	49897	Clip, Hairpin 7/8
15	4	R19212016	Washer, .6562 x 1.25 x .0598	46	1	43093	Pin, Cotter 1/8 x 1-1/2
16	2	45280	Spacer, .64 ID x .88 OD x .625	47	2	43796	Bolt, Hex 1/4-20 x 2-3/4
17	2	45279	Bearing, Flange	48	1	44950	Bolt, Carriage 1/4-20 x 3/4
18	2	48499B	Hub Cap	49	1	24858	Adjustable Stop
19	1	27276	Bracket, Drive Link Mount	50	1	47141	Nut, Nylon Wing 1/4-20
20	1	27277	Bracket, Drive Link	51	1	44101	Pin, Cotter 3/32 x 3/4
21	1	41929	Rod, Drive Link	52	2	48402	Plug, 1/4" (Christmas Tree)
22	2	43661	Bolt, Hex 1/4-20 x 1	53	1	27313	Cross Brace
23	1	41928	Rod, Flow Control	54	1	23625	Spacer
24	1	27322	Bracket, Flow Control	55	1	42839	Bushing, 3/8" Plastic
25	1	24856	Arm, Flow Control	56	1	27278	Hopper Grate
26	6	1543-69	Washer, Nylon .3281 x .75	57	1	42786	Salt Deflector
27	9	43088	Washer, 1/4 Std .312 x .734	58	2	43346	Bolt, Slot 10-32 x 5/8"
28	1	28390	Shaft, Spreader	59	2	43662	SEMS Nut, 10-32
29	2	47212	Housing, Large Gear	60	2	42784	Plastic Coated Clip
30	2	44125	Washer, .625 x 1.0 x .03		1	45367	Owner's Manual
31	1	47204	Yoke, Large				