


REPAIR PARTS FOR 45-0460 SPREADER



REPAIR PARTS FOR 45-0460 SPREADER

REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	1	48915	Hopper	25	2	43012	Hex Bolt, 1/4-20 x 3/4"
2	2	48402	1/4" Plug	26	2	23826	Angle Bracket
3	2	45164	Hex Bolt, 1/4-20 x 2-1/4"	27	6	43063	Hex Bolt, 5/16-18 x 1"
4	4	46699	Hex Bolt, 1/4-20 x 2"	28	4	43081	Washer, 5/16"
5	10	1543-69	Nylon Washer	29	1	24884	Impeller Coupler
6	8	43088	1/4" Washer	30	2	48577	Motor Lip Seal
7	10	47189	Nylock Nut, 1/4"	31	3	43010	Cotter Pin, 1/8 x 1-1/4"
8	2	25672	Clip	32	1	46554	Wire Harness
9	1	25118	Flow Slide	33	3	726-0178	Nylon Tie
10	1	44285	Bushing	34	1	49080	Vinyl Cover
11	1	24853	Guide Plate	35	1	24936	Motor Mount Bracket
12	4	43882	Pop Rivet	36	1	46562	Motor
13	1	47999	Control Cable Assembly	37	4	46334	Slotted Bolt, 8-32 x 1/2"
14	1	24937	Control Mount Bracket	38	4	43910	Washer, #10
15	1	45039	Carriage Bolt, 1/4-20 x 1-3/4"	39	4	736-0722	Lock Washer, #10
16	1	46978	Sims Nut, 1/4"	40	1	48432	Motor Cover
17	1	48983	On/Off Switch	41	2	43346	Slotted Bolt, 10-32 x 5/8"
18	1	44732	Star Washer	42	2	47171	Nylock Nut, 10-32
19	1	45082	Rubber Boot Switch	43	1	04367	Impeller
20	1	48947	Hopper Mount Tube	44	1	48559	Rear Deflector
21	1	48934	Hairpin Agitator	45	1	24946	Shaft
22	2	44180	Hex Bolt, 5/16-18 x 2"	46	1	49947	Spreader Screen
23	4	23625	Spacer, .38 x .62 x .27	47	1	40398	Control Mount Tube
24	8	47810	Nylock Nut, 5/16"		1	40977	Owners Manual