


REPAIR PARTS FOR 45-0463 130 LB. TOW SPREADER



REPAIR PARTS FOR 45-0463 130 LB. TOW SPREADER

REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	1	41084	Hopper	33	1	43010	Pin, Cotter 1/8 x 1-1/4
2	1	42008	Tube, RH Hitch Support	34	1	47209	Gear, Large (Cast)
3	1	42009	Tube, LH Hitch Support	35	1	47205	Gear, Small (Cast)
4	1	66866	Flow Control (incl. items 50 - 54)	36	1	26710	Shaft, Axle Spreader
5	1	42010	Tube, Hitch	37	1	41090	Plate, Flow
6	1	41204	Tube, Control	38	2	42011	Spring, Flow Plate
7	1	23687	Bracket, Hitch	39	1	43659	Pin, Spring, 3/16 x 1
8	2	40880	Wheel	40	1	44285	Bushing, Hopper Bottom Black
9	1	47623	Pin, Hitch 3/8" x 3" Flat Hd	41	1	49898	Clip, Hairpin 5/8
10	2	49870	Bolt, Hex 1/4-20 x 2-1/2	42	2	40315	Bearing, Flat Sided Flange
11	7	1509-69	Bolt, Hex 1/4-20 x 1-3/4	43	1	48934	Hairpin, Agitator
12	3	43648	Bolt, Hex 1/4-20 x 1-1/2	44	2	46055	Pin, Spring 1/8 x 1
13	2	43840	Bolt, Hex 5/16-18 x 1-1/4	45	1	04367	Spreader Impeller
14	1	1509-90	Bolt, Hex 1/4-20 x 1-1/4	46	4	1543-69	Washer, Nylon .3281 x .75
15	2	47810	Nut, Hex 5/16-18 Nylock	47	2	49897	Clip, Hairpin 7/8
16	14	47189	Nut, Hex 1/4-20 Nylock	48	5	43088	Washer, 1/4 Std .312 x .734
17	1	43013	Nut, Hex 1/4-20 Lock	49	2	48402	Plug, 1/4" (Christmas Tree)
18	4	R19212016	Washer, .6562 x 1.25 x .0598	50	1	41093	Cable, Flow Control (ref. 66866)
19	1	43343	Pin, Hair Cotter 3/32 x 2-5/16	51	1	41087	Flow Control Dial (ref. 66866)
20	2	48857	Spacer, .64 ID x .84 OD x 1.00	52	1	41088	Housing, Flow Control (ref. 66866)
21	1	46855	Pin, Cotter 3/16 x 2	53	1	42007	Spring, Flow Control (ref. 66866)
22	1	720-04039	Knob	54	1	41092	Shuttle, Flow Control (ref. 66866)
23	1	26733	Lever, Flow Control	55	1	41316	Vinyl Cover (optional)
24	2	48499B	Hub Cap	56	2	46699	Bolt, Hex 1/4-20 x 2
25	3	49449	Plug, 1" Tube	57	1	47856	Screw, Lag 5/16" x 3/4"
26	1	41196	Conduit Clip	58	1	43086	Lock washer, 5/16"
27	1	41097	Tube, Hopper Support LH	59	1	27170	Cross Brace
28	1	41096	Tube, Hopper Support RH	60	2	741-0475	Bushing, 3/8" Plastic
29	1	26711	Shaft, Spreader	61	1	23625	Spacer
30	2	47212	Housing, Large Gear	62	1	43177	Lock Washer, 1/4"
31	3	44125	Washer, .625 x 1.0 x .03		1	41179	Owners Manual
32	1	47204	Yoke, Large				