


Repair Parts



Repair Parts

REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	3	49449	1" Plug	26	1	28611	1/2" Axle
2	26	47189	1/4" Nylock Hex Nut (5 Extra)	27	1	6-1057BL3	Frame Assembly
3	10	43088	Washer, 5/16"	28	1	69209	Gearbox Assembly
4	1	47141	1/4" Nylon Wing Nut	29	1	43093	1/8" Cotter Pin
5	2	1543-69	Nylon Washer	30	1	2-819BL3	Leg Tube
6	1	27322BL1	Flow Control Mounting Bracket	31	2	45702Y	Wheel & Tire Assy.
7	1	24858	Adjustable Stop	32	5	43648	1/4 X 1-1/2" Hex Bolt
8	1	44950	1/4-20 X 3/4" Carriage Bolt	33	1	45428	Flow Plate
9	1	43848	Control Arm Grip	34	1	2-118	Slide Gate Bracket
10	1	24856BL1	Flow Control Arm	35	1	2-551BL3	Lower Handle Tube
11	1	42347	Torsion Spring	36	2	44482	Handle Grip
12	2	43661	1/4-20 X 1" Hex Bolt	37	1	44589BL3	Short Handle Tube
13	3	1509-69	1/4-20 X 1-3/4" Hex Bolt	38	1	23753	Gate Slide Angle Bracket
14	3	44101	3/32" Cotter Pin	39	2	C-9M5732	Rivet, Pop 3/16 SD 66 BS ZY
15	1	45431	Control Rod	40	6	43866	1/4-20 X 5/8" Carriage Bolt
16	1	28662BL3	Handle Tube	41	10	41196	7/32" Bare Clamp
17	1	48934	Hairpin Agitator	42	2	2-206	Side Deflector
18	1	45433G	Hopper	43	1	2-207	Front Deflector
19	4	49870	1/4-20 X 2-1/2" Carriage Bolt	44	4	28325	.31ID X 5/8 Spacer
20	1	45504	Impeller	45	1	2-205	85 lb. Deflector Frame Tube
21	3	R19171616	Large Washer, 17/32"	46	1	45470	Grate
22	1	44566	Torsion Spring	47	1	40883	Hopper Cover
23	1	47063	5/32" Cotter Pin		1	3-543	Owner's Manual
24	2	45705	Spacer				
25	2	47963	Flange Bearing				