


REPAIR PARTS FOR 45-0458 SPIKE AERATOR



REF	QTY	PART NO	DESCRIPTION	REF	QTY	PART NO	DESCRIPTION
1	1	26369	Shaft	6	4	1540-31	Washer, .78" x 1.25" x .062"
2	10	25429	Curved Spike Disk	7	2	44798	Flange Bearing
3	20	45148	Spike Disk Hub	8	2	41631	Cotter Pin 5/32" x 1-1/4"
4	9	44494	Spacer, .8" x 1" x 1.33"	1	1	40753-S	Owners Manual
5	2	23368	Spacer, .76" 1" x .75"				